

(fold back here)

---

## **USER TIP #1: Keeping your machine clean**

### **To prevent glue build up in the Backboard Slot:**

Use a 8 ½" X 14" shield (card stock works well) folded per this example and affixed with painter's tape. This will cover the Backboard Slot while applying the glue to paper to be padded. Then flip shield out of the way when re-inserting the Backboard for drying. Replace used shield when glue build-up accumulates. (Tip courtesy of PRH Graphics)

Note: Easy release painter's tape removes cleaner than standard masking tape.

---

(fold back here)

## **USER TIP #2: Keeping your machine clean**

### **To prevent glue build up on the Slide Table:**

Use a shield (14" X 17" card stock works well) affixed with painter's tape. Cover the aluminum angle and Slide Table preventing glue build-up while applying the glue to paper to be padded. Replace used shield when glue build-up accumulates.

(Tip courtesy of PRH Graphics)

Note: Easy release painter's tape removes cleaner than standard masking tape.